



# MC 9060<sup>ex</sup>-K

## Quick Start Guide

See Product Reference Guide for more information

POST IN WORK AREA

## Battery Insertion




Use only I-Safe Battery, type 17-A1Z0-0001

## Battery Removal

It is allowed to replace the battery in hazardous areas.




To charge the battery in hazardous areas is strictly prohibited.



## Back View

Color Camera optional

Stylus  
Stored in strap  
Strap



## Accessories for safe area

### Charging Instructions


Slow Flash = Normal Charge

Solid Amber = Full Charge

Fast Flash = Charging Error


= LED Indicator Location

safe area




Four Slot Spare Battery Charger

safe area




Single Slot Serial/USB Cradle

safe area



Four Slot Cradles


Charge-Only Cradle and Ethernet Cradle




### Optimum Imaging and Scanning Positions





Scanning/Imaging



### Optimum Upright Body Posture





### Avoid Extreme Wrist Angles



### Optimum Body Posture for Low Scanning

ALTERNATE LEFT AND RIGHT KNEES



ALTERNATE LEFT AND RIGHT HANDS